


**URK!**  
THIS MUD IS  
MURDER ON  
MY SPROCKET  
BEARINGS!


**KRUMPF**  
**GNRRRR**



# LUBE SPROCKET BEARINGS

Working in mud is murder on the dozer's sprocket bearings.

Water and dirt can get past the seals and into the bearings, causing corrosion that eats at the bearing's polished surfaces. Worn bearings knock the dozer's track out of alignment, causing excessive wear-and-tear on the vehicle's undercarriage components.



TO HEAD OFF PROBLEMS, CLEAN OFF THE MUD. THEN, LUBE THE BEARINGS EVERY TIME YOU FINISH A DAY'S RUN IN MUD OR WATER.

PUMP IN GREASE UNTIL CLEAN LUBE COMES OUT AROUND THE DIAGONAL BEARING CAP ASSEMBLY, WHICH IS BEHIND THE DRIVE SPROCKET.



**D7G Tractor Hose Assembly**

Get a new, preassembled, non-metallic hose assembly for your D7G tractor with NSN 4720-01-209-0851. That NSN will get you all the parts listed as Items 19-24 in Fig 165 of TM 5-2410-237-23P (Jul 05, w/Ch 1, Jul 06).