

# TINE ADJUSTMENT REMINDER

WHAT HAPPENED TO YOUR HAND?

IT GOT CRUNCHED WHEN HE WAS ADJUSTING MY TINES!

Operators, don't throw caution to the wind when you adjust the tines on your forklift.

When you need to adjust the tine laterally (back and forth), grab the end of one tine and lift up. Then use the flat of your other hand to adjust the tine in position. Don't let your hand or fingers get caught between the tine and forklift carriage, though. A dropped tine can easily hurt or sever a finger!

