

Job's Not Done 'Til Everything's Done



At the end of a long day, after-operation PMCS might be the last thing on your mind. But your job's not done until that job is done!

Servicing the main gun tube, bore evacuator and breech is especially important. You need to inspect, clean and service each item just like it's spelled out in the TM.

These checks are for your own safety because overlooking even small details can lead to serious consequences. For example, something as simple as a torn bore evacuator O-ring can result in a deadly flareback!

Clean the main gun tube. Remove the bore evacuator and inspect the seals. Disassemble the breech and inspect its parts.

Disassemble breech and inspect for damage

The proper procedures can be found in WPs 0455, 0456, and 0458 of TM 9-2350-264-10-3 (Dec 12) and WPs 0547, 0548, 0550 of TM 9-2350-388-10-3 (Dec 12).

