



Replace M19 Filter *ONLY*



When the M1A1 tank's M1A1-19 precleaner stops working due to lack of air flow, some units replace the entire precleaner. This isn't necessary unless the precleaner is damaged.

Most of the time the problem is that the M19 particulate filter, NSN 4240-00-866-1825, is dirty. In that case, just replace the M19 filter.

The procedures for maintaining and replacing the M19 filter are in TM 3-4240-276-30&P (Dec 97).



Usually only M19 filter needs replacing

