

HOT Tips to Keep Out the COLD

LEMME IN!
IT'S FREEZING
OUT HERE!

WON'T DO YOU
ANY GOOD! A
POWER SURGE
KNOCKED OUT
MY HEATER!

CREWMEN, IT MAY BE SPRING,
BUT THE NIGHTS CAN STILL GET
COLD. THAT'S WHERE YOUR A-20
PERSONNEL HEATER, N6N 2540-
01-396-2826, COMES IN HANDY.

KEEP YOUR
HEATER
WORKING WITH
THESE TWO
TIPS...




First

Before that cold night arrives, make sure to set the RUN-OFF-START switch on the vehicle control for the heater to OFF whenever it's slaved to another vehicle. If you don't, a power surge can damage the heater's electrical components. That'll put your heater out of action and you may not know it until you need it.

Second

Don't set your heater on HIGH (60,000 BTUs) if the temperature is above freezing. Set your heater to LOW (30,000 BTUs). If you constantly run the heater on HIGH, the wick burns out and then your warm oasis will be a cold mirage.



Flip selector switch to LOW when temps are above freezing

Turn heater switch OFF while slaving to avoid damaging heater

