


UNLOCK BEFORE POWERING UP!

HOLEY MOLEY! YOU FORGOT TO UNLOCK ME.


I THINK YOU JUST DID IN MY MAIN FRAME.





When it's time to use your common remotely operated weapons station (CROWS) II, it's important to first unlock all the locks. If CROWS is locked when you power it up, major damage to the main frame assembly can result. That can cost more than \$40,000 to fix!

Before you shoot:

- Disengage the azimuth (AZ) lock



- Put the ELEVATION (EL) transport lock in OPERATION



- Remove the SSA clamp assembly and stow it in the support equipment bag



OF COURSE, WHEN YOU'RE DONE WITH YOUR MISSION, YOU NEED TO RELOCK CROWS.