

Stryker...

KEEP TENSION *RIGHT* FOR RAMP DOOR

THE HOLD-OPEN LOCK ON YOUR STRYKER'S RAMP DOOR HAS TO BE JUST RIGHT, CREWMEN.

THERE WE GO... *JUST RIGHT!*



If it's too loose, the door won't stay open. But if it's too tight, you'll have a hard time using either the internal or external release to close the door.

Over time, and with the constant vibration generated during operation, the tension on the lock release can change. A door that was once just right is now too loose or too tight.

NOTIFY YOUR MECHANIC. HE'LL ADJUST THE TENSION BY LOOSENING OR TIGHTENING THE HEX-SOCKET SCREW ON THE DOOR'S HOLD-OPEN LOCK.



Adjust tension with hex-socket screw

