

AN/UDR-13 Radiacmeters...

WEED OUT BEEPERS!

I'M SO EMBARRASSED. I JUST CAN'T STOP BEEPING.

THAT'S OK. WE'LL TURN YOU IN TO CECOM AND GET YOU FIXED.



There are AN/UDR-13 radiacmeters in the field that have a software problem that causes them to beep. That can be beeping bad news in a combat situation.

Here's what CECOM wants you to do to weed out beeping beepers:

Turn in all AN/UDR-13s with serial numbers from 6800C to 32855C. But don't turn in any that have an "F" at the beginning of the serial number. They have been repaired and are OK.

Test all other AN/UDR-13s for beeping. Turn them on away from a radiation source and let them run for at least 20 minutes. Make sure the audio indicator is turned on. If any beep, turn them in.

Active Army and Reserves should follow the turn-in procedure in Ground Precautionary Action 2014-005 at:

<https://cecomsafety.apg.army.mil/sfmessages2/>

ARNG units should contact their surface maintenance manager for turn-in instructions.

Marines should contact their local CBRN office.

For more information, contact CECOM's Thomas Lamphear at DSN 648-1381, (443) 395-1381, or email: thomas.m.lamphear.civ@mail.mil

Test all radiacmeters for beeping

