

FASTER FILLING

ARRGH!
THIS IS TAKING
FOREVER!
THERE **MUST** BE
A **FASTER** WAY
TO DO THIS!



Dear Editor,


It takes forever to fill the M13 decon's trainer with water. The fill hole in the container is small and it's a pain to keep pouring water through the funnel.

We make things easier here at the Chemical School by connecting an old M13 hose quick-disconnect to a garden hose. Use a 1-in clamp to hold the quick-disconnect in place. Then connect that end of the hose to the M13 quick connect plug and the other end to a faucet. Turn on the water and watch the trainer fill up.

We also tell students that when pumping, they should hold the rear of the pump with a rag or old glove. That will prevent their hand from being pinched or their butyl rubber glove from being torn.



Attach quick-disconnect
to hose with clamp



Brad Perkins
US Army Chemical School
Ft Leonard Wood, MO

