



Turn Off Heater *Before* BIT



If the heater for the AN/PSQ-23 and -23A small tactical optical rifle mounted (STORM) laser range finder is on when you do the built-in-test (BIT) procedures, the STORM will fail. So it's important to remember to turn off the heater before doing the BIT.

But if your STORM is placed in the Stryker configuration and connected to a Stryker vehicle, you may not realize the heater turns on automatically once it's connected to an external power source.

To turn the heater off before doing the BIT function, follow the procedures in WP 00 10-5 in TM 9-5855-1913-13&P (Aug 12) or TM 9-5855-1920-13&P (Jul 12). Or you can exit the Stryker configuration and select the GRMN or PLGR menu options.

Questions? Contact TACOM's Dennis Timmons at DSN 786-1371, (586) 282-1371, or email:

dennis.c.timmons.civ@mail.mil

or Anthony Smith at DSN 786-1233, (586) 282-1233, or email:

anthony.g.smith30.civ@mail.mil